

How to Disengage

1 Always start by disengaging on the long side



2 Grab the planks with both hands and gently lift at the same time until the planks disengage



3 Place the planks gently on the floor



4 To disengage on the short side, slide the planks the opposite direction



5 Press the planks gently while sliding



6 Continue sliding until the planks are fully separated



*Do not pull plank up to disengage end joints. This will damage the locking mechanism.

Technical Support: 423-794-0601